



Owner's Manual

MADISON 9' UMBRELLA

Product Code: D71 34470
UPC Code: 885227001081

Date of Purchase: ____ / ____ / ____

PARTS

Read through all the instructions before beginning assembly. Unpack and identify all the parts. Place them on a flat, non-abrasive surface. Assembly by two people is recommended.

ITEM	DESCRIPTION	QUANTITY
A	Umbrella Top	1
B	Bottom Pole	1




IMPORTANT ASSEMBLY TIPS

To avoid potential damage to the umbrella, please read the following instructions before using. Failure to follow instructions may result in permanent damage to the umbrella.

ASSEMBLY INSTRUCTIONS

1



CARE INSTRUCTIONS

Umbrella-Wash with a mild solution of soap and water, allow umbrella to drip dry in the open position. Dry umbrella pole completely. Keep umbrella closed when not in use. To prevent damage to your table, always use an umbrella base with your umbrella. In extreme windy conditions, it is recommended that you remove the umbrella from the table and store.

sears

Please refer to part numbers when reordering
For questions or comments about product:
Email: acs@americancustomerservice.com or Call toll-free: 1-888-577-9825

Made in / Hecho en CHINA
Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com